


STEP 1:

- Turn on device
- Turn off mobile's data connection
 - Open Wi-Fi manager




STEP 2:

- Click the SSID “**DENONTEK-280**”




Step 3:

- Enter Default password “**123456789**”
 - Click connect




STEP 4:

- If following prompt appears, click “CONNECT” OR “STAY CONNECTED”



STEP 5:

- Open Google Chrome browser
- For Vivo/ Oppo/ Infinix download “Samsung Internet” from play store.




STEP 6:

- Enter IP “**192.168.4.1**” into address bar as follow, hit Enter or Go




STEP 7:

- Enter default key "**123**" and Login.



STEP 8:

- After login following screen will appear.



www.denontek.com



ORDER NOW

03344778077




Consider the following sample time table


SAMPLE TIMETABLE

NO.	MON TO SAT	FRIDAY	REMARKS
0	7:30	7:30	SCHOOL START
1	7:45	7:45	ASSMB.
2	8:30	8:15	LECTURE 1 OFF
3	9:15	8:45	LECTURE 2 OFF
4	10:00	9:15	LECTURE 3 OFF
5	10:45	9:45	LECTURE 4 OFF
6	11:30	10:15	BREAK START
7	12:15	10:45	BREAK OFF
8	13:00	11:15	LECTURE 5 OFF
9	13:45	11:45	LECTURE 6 OFF
10	14:30	12:15	SCHOOL OFF

Monday to Saturday
Timings



Friday Timings



www.denontek.com



ORDER NOW

03344778077



www.denontek.com



ORDER NOW

03344778077